

MID Range Reader Wiring Diagram



Red – 12V
Black – GND
Green – D0
White – D1

MR-00MR-003

Specifications:

> Frequency: 125KHz

Card Type : EM Proximity Card

Respond Distance: 50-100 cm (Depends on Site Condition and System compatibility)

Output Format : Wiegand 26

> Operation Voltage : DC12V-15V

➤ Operating Current : 100mA

> Size : 235 x 240 x 35 (mm)

Color: Black

➤ Operation Temperature : -10°C to 50°C

Recommended Practices for Installations

- Check the power input connections and make sure that they are not reversed.
- ➤ When external Power is used, make sure sharing the power with Controller or share the same GND.
- Advice use 4 cores stranded alarm cable to connect the reader to controller (suggested use 0.22 square millimeters and the length should not exceed 100 meters).
- Make sure not to install the reader near to conductive surface.
- > Try to install reader to another place if still has reading problem